# **COMMON PROCEDURAL ROOM**

## **PPE Recommendations**

## **Prior to Procedural Room Entry:**



#### **Facility entrance:**

- 1. Shoe covers
- 2. Gown

#### **Outside room:**

- 1. Bouffant
- 2. Surgical Mask

### **Prior to Handling Mice:**



#### **Facility entrance:**

- 1. Shoe covers
- 2. Gown

#### **Outside room:**

- 1. Bouffant
- 2. Surgical mask

#### Inside room:

- 1. Tyvek sleeves
- 2. Gloves (i.e., double gloves if immunodeficient mice)
- 3. Spray gloves with Oxivir Tb

**Surfaces** that may come into contact with mice, including benchtops, biosafety cabinets, anesthesia induction chambers & nosecones, portable equipment, and gloved hands must be disinfected by **saturate spraying with Oxivir Tb**, or by **use of Oxivir Tb wipes** in accordance with SOP 1015 prior to and after each use.