

**INSTRUCTIONS FOR USE OF
CLASS II BIOLOGICAL SAFETY CABINET**

**TURN BLOWER ON 15 MINUTES PRIOR TO USE
DISINFECT INTERIOR SURFACES BEFORE WORK
COMMENCES**

PLACE EQUIPMENT/SUPPLIES INTO CABINET

**ALLOW 2-3 MINUTES FOR THE CABINET TO
PURGE AFTER PLACING MATERIALS IN IT**

SLEEVES MUST BE WORN WHILE WORKING

**DISINFECT INTERIOR SURFACES UPON
COMPLETION OF WORK**

SC #044.2
Eff. 6/17

4 X 6