

NOTE: Your gloves, the anesthesia induction chamber, animal resting surface, and anesthetic manifold must be sanitized with Oxivir wipes, and allowed **5 minutes** to effectively decontaminate, Allow your Oxivir-decontaminated gloves to dry before handling mice prior to anesthetic induction.

SC195.2
Effective 12/17

3.5 x 5