

## Instrument Schedule

*MUS Concert Hall*

Position	Unit #	Dim. #	Dim. Type	DMX Start	Pwr	Fixt. #	Inst Type	Watt.	Purpose	Focus	Color	Accessories
Cloud A	1	19	Sensor	1		66	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	2	117	SineWave			119	S4-26°	750w	Front	B1	R 119	
	3	117	SineWave			119	S4-26°	750w	Front	B1	R 119	
	4	119	SineWave			123	Source 4 PARNeI	750w	Top	A	R 119	7.5" 4 Leaf Barn Door
	5	23	Sensor			25	Source 4 PARNeI	750w	Top	A	R 119	7.5" 4 Leaf Barn Door
	6	24	Sensor	5		66	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	7	111	SineWave			118	S4-26°	750w	Front	C1	R 119	
	8	119	SineWave			123	Source 4 PARNeI	750w	Top	B	R 119	
	9	25	Sensor			24	Source 4 PARNeI	750w	Top	B	R 119	
	10	112	SineWave			122	Source 4 PARNeI	750w	Top	C	R 119	
	11	113	SineWave			117	S4-26°	750w	Front	D1	R 119	
	12	26	Sensor			23	Source 4 PARNeI	750w	Top	C	R 119	
	13	115	SineWave			121	Source 4 PARNeI	750w	Top	D	R 119	
	14	28	Sensor			22	Source 4 PARNeI	750w	Top	D	R 119	
	15	114	SineWave			116	S4-26°	750w	Front	E1	R 119	
	16	29	Sensor	45		61	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	17	115	SineWave			121	Source 4 PARNeI	750w	Top	E	R 119	7.5" 4 Leaf Barn Door
	18	30	Sensor			21	Source 4 PARNeI	750w	Top	E	R 119	7.5" 4 Leaf Barn Door
	19	116	SineWave			115	S4-26°	750w	Front	F1	R 119	
	20	116	SineWave			115	S4-26°	750w	Front	F1	R 119	
	21	32	Sensor	41		61	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat

## Instrument Schedule

*MUS Concert Hall*

Position	Unit #	Dim. #	Dim. Type	DMX Start	Pwr	Fixt. #	Inst Type	Watt.	Purpose	Focus	Color	Accessories
Cloud B	1	33	Sensor	9		67	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	2	118	SineWave			126	Source 4 PARNeI	750w	Top	F	R 119	7.5" 4 Leaf Barn Door
	3	34	Sensor			32	Source 4 PARNeI	750w	Top	F	R 119	7.5" 4 Leaf Barn Door
	4	118	SineWave			126	Source 4 PARNeI	750w	Top	G	R 119	
	5	35	Sensor			31	Source 4 PARNeI	750w	Top	G	R 119	
	6	36	Sensor	13		67	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	7	118	SineWave			126	Source 4 PARNeI	750w	Top	H	R 119	
	8	37	Sensor			30	Source 4 PARNeI	750w	Top	H	R 119	
	9	120	SineWave			125	Source 4 PARNeI	750w	Top	J	R 119	
	10	39	Sensor			29	Source 4 PARNeI	750w	Top	J	R 119	
	11	121	SineWave			124	Source 4 PARNeI	750w	Top	K	R 119	
	12	41	Sensor			28	Source 4 PARNeI	750w	Top	K	R 119	
	13	42	Sensor	53		62	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	14	121	SineWave			124	Source 4 PARNeI	750w	Top	L	R 119	
	15	43	Sensor			27	Source 4 PARNeI	750w	Top	L	R 119	
	16	121	SineWave			124	Source 4 PARNeI	750w	Top	M	R 119	7.5" 4 Leaf Barn Door
	17	44	Sensor			26	Source 4 PARNeI	750w	Top	M	R 119	7.5" 4 Leaf Barn Door
	18	45	Sensor	49		62	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat

## Instrument Schedule

*MUS Concert Hall*

Position	Unit #	Dim. #	Dim. Type	DMX Start	Pwr	Fixt. #	Inst Type	Watt.	Purpose	Focus	Color	Accessories
Cloud C	1	46	Sensor	17		68	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	2	127	SineWave			129	Source 4 PARNeI	750w	Top	N	R 119	7.5" 4 Leaf Barn Door
	3	47	Sensor			39	Source 4 PARNeI	750w	Top	N	R 119	7.5" 4 Leaf Barn Door
	4	49	Sensor	21		68	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	5	127	SineWave			129	Source 4 PARNeI	750w	Top	O	R 119	
	6	48	Sensor			38	Source 4 PARNeI	750w	Top	O	R 119	
	7	127	SineWave			129	Source 4 PARNeI	750w	Top	P	R 119	
	8	50	Sensor			37	Source 4 PARNeI	750w	Top	P	R 119	
	9	124	SineWave			128	Source 4 PARNeI	750w	Top	Q	R 119	
	10	53	Sensor			36	Source 4 PARNeI	750w	Top	Q	R 119	
	11	122	SineWave			127	Source 4 PARNeI	750w	Top	R	R 119	
	12	54	Sensor			35	Source 4 PARNeI	750w	Top	R	R 119	
	13	55	Sensor	61		63	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	14	122	SineWave			127	Source 4 PARNeI	750w	Top	S	R 119	
	15	56	Sensor			34	Source 4 PARNeI	750w	Top	S	R 119	
	16	122	SineWave			127	Source 4 PARNeI	750w	Top	T	R 119	7.5" 4 Leaf Barn Door
	17	57	Sensor			33	Source 4 PARNeI	750w	Top	T	R 119	7.5" 4 Leaf Barn Door
	18	58	Sensor	57		63	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat

## Instrument Schedule

*MUS Concert Hall*

Position	Unit #	Dim. #	Dim. Type	DMX Start	Pwr	Fixt. #	Inst Type	Watt.	Purpose	Focus	Color	Accessories
Cloud D	1	59	Sensor	25		69	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	2	126	SineWave			132	Source 4 PARNeI	750w	Top	U	R 119	7.5" 4 Leaf Barn Door
	3	60	Sensor			46	Source 4 PARNeI	750w	Top	U	R 119	7.5" 4 Leaf Barn Door
	4	126	SineWave			132	Source 4 PARNeI	750w	Top	V	R 119	
	5	61	Sensor			45	Source 4 PARNeI	750w	Top	V	R 119	
	6	62	Sensor	29		69	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	7	126	SineWave			132	Source 4 PARNeI	750w	Top	W	R 119	
	8	63	Sensor			44	Source 4 PARNeI	750w	Top	W	R 119	
	9	128	SineWave			131	Source 4 PARNeI	750w	Top	X	R 119	
	10	66	Sensor			43	Source 4 PARNeI	750w	Top	X	R 119	
	11	123	SineWave			130	Source 4 PARNeI	750w	Top	Y	R 119	
	12	67	Sensor			42	Source 4 PARNeI	750w	Top	Y	R 119	
	13	68	Sensor	69		64	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	14	123	SineWave			130	Source 4 PARNeI	750w	Top	Z	R 119	
	15	69	Sensor			41	Source 4 PARNeI	750w	Top	Z	R 119	
	16	123	SineWave			130	Source 4 PARNeI	750w	Top	A1	R 119	7.5" 4 Leaf Barn Door
	17	70	Sensor			40	Source 4 PARNeI	750w	Top	A1	R 119	7.5" 4 Leaf Barn Door
	18	71	Sensor	65		64	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat

## Instrument Schedule

*MUS Concert Hall*

Position	Unit #	Dim. #	Dim. Type	DMX Start	Pwr	Fixt. #	Inst Type	Watt.	Purpose	Focus	Color	Accessories
Cloud E	1	72	Sensor	33		70	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	2	-	Switched	267		98	VL1100AS	575w	Special			
	3	125	SineWave			135	Source 4 PARNeI	750w	Top	B1	R 119	7.5" 4 Leaf Barn Door
	4	74	Sensor			51	Source 4 PARNeI	750w	Top	B1	R 119	7.5" 4 Leaf Barn Door
	5	75	Sensor	37		70	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	6	125	SineWave			135	Source 4 PARNeI	750w	Top	C1	R 119	7.5" 4 Leaf Barn Door
	7	76	Sensor			50	Source 4 PARNeI	750w	Top	C1	R 119	7.5" 4 Leaf Barn Door
	8	130	SineWave			135	Source 4 PARNeI	750w	Top	D1	R 119	7.5" 4 Leaf Barn Door
	9	129	SineWave			133	Source 4 PARNeI	750w	Top	E1	R 119	7.5" 4 Leaf Barn Door
	10	80	Sensor			48	Source 4 PARNeI	750w	Top	E1	R 119	7.5" 4 Leaf Barn Door
	11	78	Sensor			49	Source 4 PARNeI	750w	Top	D1	R 119	7.5" 4 Leaf Barn Door
	12	81	Sensor	77		65	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
	13	129	SineWave			133	Source 4 PARNeI	750w	Top	F1	R 119	7.5" 4 Leaf Barn Door
	14	73	Sensor			47	Source 4 PARNeI	750w	Top	F1	R 119	7.5" 4 Leaf Barn Door
	15	-	Switched	294		97	VL1100AS	575w	Special			
	16	84	Sensor	73		65	S4-26° w Seachanger	750w	High Side		R 119	6.25" Short Top Hat
SL Low Box Boom	1		Switched	213		96	VL1100AS	575w	Special			
SL High Box Boom	1	88	Sensor	93	168	74	Seachanger Wash	750w	Wash			
	2	89	Sensor	97	168	75	Seachanger Wash	750w	Wash			
	3	90	Sensor	101	168	76	Seachanger Wash	750w	Wash			
SR Low Box Boom	1		Switched	240		95	VL1100AS	575w	Special			
SR High Box Boom	1	85	Sensor	81	171	71	Seachanger Wash	750w	Wash			
	2	86	Sensor	85	171	72	Seachanger Wash	750w	Wash			
	3	87	Sensor	89	171	73	Seachanger Wash	750w	Wash			

## Instrument Schedule

*MUS Concert Hall*

Position	Unit #	Dim. #	Dim. Type	DMX Start	Pwr	Fixt. #	Inst Type	Watt.	Purpose	Focus	Color	Accessories
Truss #1	1	104	SineWave			114	S4-26°	750w	Front	N	R 119	
	2	10	Sensor			14	S4-26°	750w	Front	N	R 119	
	3		Switched	159		94	VL1100AS	575w	Special			
	4	105	SineWave			113	S4-26°	750w	Front	O	R 119	
	5	11	Sensor			13	S4-26°	750w	Front	O	R 119	
	6	106	SineWave			112	S4-26°	750w	Front	P	R 119	
	7	12	Sensor			12	S4-26°	750w	Front	P	R 119	
	8	13	Sensor			84	S4 Zm 15°-30°	750w	Special		R 119	
	9	107	SineWave			111	S4-26°	750w	Front	Q	R 119	
	10	14	Sensor			11	S4-26°	750w	Front	Q	R 119	
	11	15	Sensor			83	S4 Zm 15°-30°	750w	Special		R 119	
	12	108	SineWave			110	S4-26°	750w	Front	R	R 119	
	13	16	Sensor			10	S4-26°	750w	Front	R	R 119	
	14	109	SineWave			109	S4-26°	750w	Front	S	R 119	
	15	17	Sensor			9	S4-26°	750w	Front	S	R 119	
	16		Switched	186		93	VL1100AS	575w	Special			
	17	110	SineWave			108	S4-26°	750w	Front	T	R 119	
	18	18	Sensor			8	S4-26°	750w	Front	T	R 119	

## Instrument Schedule

*MUS Concert Hall*

Position	Unit #	Dim. #	Dim. Type	DMX Start	Pwr	Fixt. #	Inst Type	Watt.	Purpose	Focus	Color	Accessories
Truss #2	1	97	SineWave			107	S4-26°	750w	Front	F	R 119	
	2	1	Sensor			7	S4-26°	750w	Front	F	R 119	
	3	-	Switched	105		92	VL1100AS	575w	Special			
	4	98	SineWave			105	S4-26°	750w	Front	A	R 119	
	5	2	Sensor			5	S4-26°	750w	Front	A	R 119	
	6	99	SineWave			104	S4-26°	750w	Front	B	R 119	
	7	3	Sensor			4	S4-26°	750w	Front	B	R 119	
	8	4	Sensor			82	S4 Zm 15°-30°	750w	Special		R 119	
	9	100	SineWave			103	S4-26°	750w	Front	C	R 119	
	10	5	Sensor			3	S4-26°	750w	Front	C	R 119	
	11	6	Sensor			81	S4 Zm 15°-30°	750w	Special		R 119	
	12	101	SineWave			102	S4-26°	750w	Front	D	R 119	
	13	7	Sensor			2	S4-26°	750w	Front	D	R 119	
	14	102	SineWave			101	S4-26°	750w	Front	E	R 119	
	15	8	Sensor			1	S4-26°	750w	Front	E	R 119	
	16	-	Switched	132		91	VL1100AS	575w	Special			
	17	103	SineWave			106	S4-26°	750w	Front	M	R 119	
	18	9	Sensor			6	S4-26°	750w	Front	M	R 119	